
<u>DMX512 Traits</u>		
DMX- Value	Channel 1	Channel 2
	Strobe Speed	Dimmer
240~255	Speed 15	Dimmer 15
224~239	Speed 14	Dimmer 14
208~223	Speed 13	Dimmer 13
192~207	Speed 12	Dimmer 12
176~191	Speed 11	Dimmer 11
160~175	Speed 10	Dimmer 10
144~159	Speed 9	Dimmer 9
128~143	Speed 8	Dimmer 8
112~127	Speed 7	Dimmer 7
96~111	Speed 6	Dimmer 6
80~95	Speed 5	Dimmer 5
64~79	Speed 4	Dimmer 4
48~63	Speed 3	Dimmer 3
32~47	Speed 2	Dimmer 2
16~31	Speed 1	Dimmer 1
0~15	STOP	BLACKOUT

MASTER/SLAVE MODE

By linking the units in master/slave connection, the first unit will control the other units to give an automatic light show. You will know which unit is the master because its DMX input jack will have nothing plugged into it. The other units (slaves) will have DMX cables plugged into the DMX input jacks (daisy chain). You can set the units in below two ways:

- 1. **Synchronized show:** set the first (Master) unit's dipswitches 1 and 10 to ON, now you can adjust the dimmer and strobe speed, and all the other (slave) units will follow the Master unit.
- 2. **4-units Lightshow:** set the dipswitch as the diagram, the first (master) unit will run the built-in programmer and control the other (slave) units separately like a 4 channel chaser.



Chase pattern in the 4-units lightshow mode:

Pattern 1	Units 1,2,3,4 all Full on
Pattern 2	Chase unit 1->2->3->4 — 4->3->2->1
Pattern 3	Chase unit 1->2->3->4-4->3->2->1
Pattern 4	Chase Units1&2->3&4 — 2&3->1&4
Pattern 5	Chase 1-1&2-1&2&3-ALL-1&2&3-1&2-1-stop — 4-4&3-4&3&2-ALL-4&3&2-4&3-4-stop
Pattern 6	Chase 1->2->1->2->3->4->3->4—4->1->4->1->3->2->3->2